



# PROMAR<sup>®</sup> 200

## Zero VOC Interior Latex Primer B28W02600

As of 05/17/2016, Complies with:			
OTC	Yes	LEED <sup>®</sup> 09 NC CI	Yes
SCAQMD	Yes	LEED <sup>®</sup> 09 CS	Yes
CARB	Yes	LEED <sup>®</sup> 09 H & S	Yes
CARB SCM 2007	Yes	LEED <sup>®</sup> v4 Emissions	Yes
MPI	Yes	LEED <sup>®</sup> v4 VOC	Yes

<u>DESCRIPTION</u>	<u>CHARACTERISTICS</u>	<u>SURFACE PREPARATION</u>
<p><b>ProMar 200 Zero VOC Interior Latex Primer</b> is a durable, professional quality, interior vinyl acrylic primer.</p> <p>This primer has been designed for use with the ProMar Series Interior Latex topcoats providing a complete system.</p> <p><b>For use on these interior surfaces:</b></p> <ul style="list-style-type: none"> <li>• Wood</li> <li>• Drywall</li> <li>• Plaster</li> <li>• Masonry</li> <li>• Primed Metal</li> <li>• Previously painted surfaces</li> </ul>	<p><b>Color:</b> White</p> <p><b>Coverage:</b> 350 - 400 sq ft/gal @ 4 mils wet; 1.0 mils dry</p> <p><b>Drying Time, @ 77°F, 50% RH:</b></p> <p>Touch: 1 hour Recoat: 4 hours</p> <p>Drying and recoat times are temperature, humidity and film thickness dependent.</p> <p><b>Flash Point:</b> N/A</p> <p><b>Finish:</b> 0 - 5 units @ 85°</p> <p><b>Vehicle Type:</b> Vinyl Acrylic</p> <p><b>B28W02600</b></p> <p><b>VOC (less exempt solvents):</b> &lt;50 g/L; &lt;0.42 lb/gal As per 40 CFR 59.406 and SOR/2009-264, s.12</p> <p><b>Volume Solids:</b> 26 ± 2%</p> <p><b>Weight Solids:</b> 43 ± 2%</p> <p><b>Weight per Gallon:</b> 10.77 lb</p> <p><b>WVP Perms (US)</b> 25.8 grains/(hr ft<sup>2</sup> in Hg)</p> <p><b>Tinting</b> Requires ColorCast Ecotoners for tinting. For best topcoat color development, use the recommended "P"-shade primer. If desired, up to 4 oz per gallon of ColorCast Ecotoners can be used to approximate the topcoat color. Check color before use.</p> <p>When spot priming on some surfaces, a non-uniform appearance of the final coat may result, due to differences in holdout between primed and unprimed areas. To avoid this, prime the entire surface rather than spot priming.</p> <p>For optimal performance, this primer must be topcoated with a latex, alkyd/oil, water based epoxy, or solvent based epoxy coating on architectural applications.</p>	<p><b>WARNING!</b> Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at <b>1-800-424-LEAD</b> (in US) or contact your local health authority.</p> <p>Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer/sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.</p> <p><b>Caulking</b> Fill gaps between walls, ceilings, crown moldings, and other trim with the appropriate caulk after priming the surface.</p> <p><b>Drywall</b> Fill cracks and holes with patching paste/spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.</p>



**PROMAR<sup>®</sup> 200**  
 Zero VOC  
 Interior Latex  
 Primer  
 B28W02600

<u><b>SURFACE PREPARATION</b></u>	<u><b>APPLICATION</b></u>	<u><b>CAUTIONS</b></u>
<p><b>Masonry, Concrete, Cement, Block</b>            All new surfaces must be cured according to the supplier's recommendations—usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with Loxon Concrete &amp; Masonry Primer.</p> <p><b>Mildew</b>            Prior to attempting to remove mildew, it is always recommended to test any cleaner on a small, inconspicuous area prior to use. Bleach and bleaching type cleaners may damage or discolor existing paint films. Bleach alternative cleaning solutions may be advised.            Mildew may be removed before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach/water solution.</p> <p><b>Plaster</b>            Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p>	<p>Use at temperatures above 50°F.            No reduction necessary.</p> <p><b>Brush</b>            Use a nylon/polyester brush.</p> <p><b>Roller</b>            Use a synthetic nap cover</p> <p><b>Spray - Airless</b>            Pressure .....2000 psi            Tip.....017"-021"</p> <p><u><b>CLEANUP INFORMATION</b></u>            Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with a compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.</p>	<p>For interior use only.            Protect from freezing.            Non-photochemically reactive.            Not for use under wallpaper.</p> <p>Before using, carefully read <b>CAUTIONS</b> on label.</p> <p>HOTW 05/17/2016 B28W02600 21 00            KOR, FRC, SP</p> <p>The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative or visit <a href="http://www.paintdocs.com">www.paintdocs.com</a> to obtain the most current version of the PDS and/or an SDS.</p>